


YII-630 Top &
Bottom hook assy.

DETAIL DRAWING

(94.1.20)

YII-80.100.160.320.630.900



- 63 Bottom Hook Assy for 6.3t
- 64 Bottom hook cover for 6.3t
- 65 Fly wheel for 6.3t
- 66 Fly wheel pin set for 6.3t
- 67 Bolt w/hex. hole
- 68 Hex. nut
- 69 Spring washer

- 1 Top hook set
- 2 Safety latch
- 3 Spring for safety latch
- 4 Hex. nut
- 5 Hex. nut
- 6 Top hook pin
- 7 Bottom hook pin set
- 8 Chain stop bolt
- 9 Castle nut
- 10 Cotter pin
- 11 Hex. nut
- 12 Spring washer
- 13 Ratchet
- 14 Ratchet spring
- 15 E-ring
- 16 Gear cover set
- 17 Pinion shaft
- 18 Wash for pinion shaft

- 21 Castle nut
- 22 Cotter pin
- 23 Second & Third gear assy.
- 24 Load gear
- 25 Load sheave
- 26 Chain guide set
- 27 Chain stripper
- 28 Disc hub
- 29 E-ring for disc hub
- 30 Ratchet wheel
- 31 Friction disc
- 32 Lever assy.
- 33 Lever grip
- 34 Pair screw
- 35 Hex. nut
- 36 Spring washer
- 37 Feed gear
- 38 Ratchet for feed gear

- 40 Ratchet spring pin
- 41 Spring case
- 42 Lever cover
- 43 Hex. bolt w/cross hole
- 44 Brake cover
- 45 Cover stop ring
- 46 C ring
- 47 Load chain
- 48 Gear side plate assy.
- 49 Lever side plate assy.
- 50 Ratchet spring
- 51 Collar
- 52 Spring for floating
- 53 Feed handle
- 54 Spring
- 55 Spring receiver
- 56 Chain stopper

- 19 Bottom Hook Assy. for 9t
- 20 Bottom hook cover for 9t
- 21 Fly wheel for 9t
- 22 Fly wheel pin set for 9t
- 23 Bolt w/hex. hole
- 24 Hex. nut
- 25 Spring washer
- 26 Top hook Assy. for 9t
- 27 Arm for 9t
- 28 Bolt w/hex. hole
- 29 Hex. nut
- 30 Spring Washer

YII-900 Top &
Bottom hook assy.

- 8 Bottom Hook Assy. for 9t
- 9 Bottom hook cover for 9t
- 10 Fly wheel for 9t
- 11 Fly wheel pin set for 9t
- 12 Bolt w/hex. hole
- 13 Hex. nut
- 14 Spring washer
- 15 Top hook Assy. for 9t
- 16 Arm for 9t
- 17 Bolt w/hex. hole
- 18 Hex. nut
- 19 Spring Washer